


Cartridge HP No.45, 51645ae, černá

» Kancelář » Tonery a cartridge » Hewlett-Packard » Originál



Množství v balení
Kód produktu

1

9107451

Skladem:

Na objednávku

Cartridge HP No.45, 51645ae, černá

» Kancelář » Tonery a cartridge » Hewlett-Packard » Originál

Popis

Vhodné pro tiskárny: HP DESKJET 980CXI, HP PHOTOSMART P1115, HP PHOTOSMART P1100, HP PHOTOSMART P1000, HP PHOTOSMART 1315, HP PHOTOSMART 1218, HP PHOTOSMART 1215, HP PHOTOSMART 1115, HP PHOTOSMART 1100, HP PHOTOSMART 1000, HP DESIGNJET 700, HP DESIGNJET 750C, HP DESIGNJET 750C PLUS, HP DESIGNJET 755CM, HP DESKJET 1100C, HP DESKJET 1125C, HP DESKJET 1215, HP DESKJET 1218, HP DESKJET 1600C, HP DESKJET 1600CM, HP OFFICEJET 1175C, HP OFFICEJET 1170 CXI, HP FAX 1220, HP DESKJET 6120, HP DESKJET 6122, HP DESKJET 6127, HP DESKJET 710C, HP DESKJET 720C, HP DESKJET 722C, HP DESKJET 815C, HP DESKJET 820CXI, HP DESKJET 850C, HP DESKJET 870CXI, HP DESKJET 880C, HP DESKJET 890C, HP DESKJET 894CXI, HP DESKJET 895CXI, HP DESKJET 9300, HP DESKJET 930C, HP DESKJET 950C, HP DESKJET 959C, HP DESKJET 960C, HP DESKJET 969C, HP DESKJET 970CXI, HP DESKJET 990CXI, HP DESKJET 995C, HP DESIGNJET 330, HP OFFICE JET PRO 1150C, HP OFFICE JET PRO 1175C, HP COLOR COPIER 110, HP DESKJET 820PRO, HP OFFICE JET PRO 1170C, HP OFFICE JET T45, HP OFFICE JET T65, HP OFFICE JET R45, HP OFFICE JET R65, HP PHOTOSMART P1215, HP PHOTOSMART P1218, HP OFFICE JET K60, HP OFFICE JET K80, HP OFFICE JET G55, HP OFFICE JET G85, HP OFFICE JET G95, HP DESKJET 960, HP DESKJET 990C, HP DESKJET 1220PS, HP DESKJET 930CM, HP DESKJET 990CM, HP OFFICEJET PRO 1175C, HP OFFICEJET T 45, HP OFFICEJET T 65, HP OFFICEJET R 45, HP OFFICEJET R 65, HP OFFICEJET K 80, HP DESIGNJET 800CC, HP 800CC, HP OFFICEJET PRO 1150C, HP OFFICEJET PRO 1170C, HP DESKJET 1280, HP DESKJET 1200CSE, HP OFFICEJET R 40, HP OFFICEJET R 60, HP PSC 700, HP PSC 900, HP QUIETJET PLUS, HP QUIETJET, HP THINKJET, HP DESKJET 980C, HP OFFICEJET 5100, HP COLOR COPIER 140, HP COPYJET, HP DESIGNJET 400, HP DESIGNJET 488C, HP DESIGNJET 650C, HP DESIGNJET 650PS, HP DESIGNJET 710C, HP DESIGNJET 712C, HP DESIGNJET 720C, HP DESIGNJET 722C, HP DESIGNJET 755CM PLUS, HP DESKJET 1000, HP DESKJET 1000C, HP DESKJET 1180C, HP DESKJET 1220CSE, HP DESKJET 6100, HP DESKJET 700, HP DESKJET 712C, HP DESKJET 800, HP DESKJET 812C, HP DESKJET 820C, HP DESKJET 820CE, HP DESKJET 820CSE, HP DESKJET 825CVR, HP DESKJET 830, HP DESKJET 830C, HP DESKJET 832, HP DESKJET 832C, HP DESKJET 845CVR, HP DESKJET 850CXI, HP DESKJET 855CSE, HP DESKJET 870CSE, HP DESKJET 882C, HP DESKJET 890CM, HP DESKJET 890CSE, HP DESKJET 890CXI, HP DESKJET 895CSE, HP DESKJET 900, HP DESKJET 920CVR, HP DESKJET 920CXI, HP DESKJET 932C, HP DESKJET 935C, HP DESKJET 940CVR, HP DESKJET 952C, HP DESKJET 970CSE, HP DESKJET 990CSE, HP DIGITAL COPIER 310, HP FAX 1220XI, HP KODAK DIGITAL SCIENCE PSA 1000, HP OFFICEJET 5105, HP OFFICEJET 5110V, HP OFFICEJET 5110XI, HP OFFICEJET G, HP OFFICEJET G 85, HP OFFICEJET G 85XI, HP OFFICEJET G 55, HP OFFICEJET K, HP OFFICEJET K 60, HP OFFICEJET K 60XI, HP OFFICEJET K 80XI, HP OFFICEJET PRO 1150CSE, HP OFFICEJET PRO 1170CSE, HP OFFICEJET PRO 1175CSE, HP OFFICEJET PRO 1175CXI, HP OFFICEJET PRO 5100, HP OFFICEJET PRO 5105, HP OFFICEJET PRO 5110, HP OFFICEJET PRO 5110V, HP OFFICEJET PRO 5110XI, HP OFFICEJET R, HP OFFICEJET R 40XI, HP OFFICEJET R 80, HP OFFICEJET R 80XI, HP OFFICEJET T, HP OFFICEJET T 45XI, HP OFFICEJET T 65XI, HP OFFICEJET V, HP OFFICEJET V 30, HP P 1100, HP P 1100XI, HP P 1115, HP PHOTOSMART 1200, HP PHOTOSMART 1215VM, HP PHOTOSMART 1218XI, HP PHOTOSMART 1300, HP PHOTOSMART 1600C, HP PHOTOSMART 3120C, HP PHOTOSMART 3810, HP PHOTOSMART 3816, HP PHOTOSMART 3820, HP PHOTOSMART 6100, HP PHOTOSMART 6122, HP PHOTOSMART 6127, OLIVETTI JOB JET P200, HP DESKJET 830 SERIES, HP DESKJET 832C SERIES, HP DESKJET 970C SERIES, HP DESKJET 980C SERIES, HP DESKJET 1120C, HP DESKJET 1220C, HP OFFICEJET G 95.

Parametry

Množství v balení

1