






ESTER - montážní návod

A		5
B		1
C		1
D		1
E		1
F		1

G	 M6x30mm	6
G1	 M8x20mm	8
G2	 M6x20mm	2
H		2
I		1
L	 5#	1

